DVD VIDEO PLAYER DVP3000K

User manual

Thank you for choosing Philips.

Need help fast?

Read your User's Manual first for quick tips that make using your Philips product more enjoyable.
If you have read your instructions and still need assistance, you may access our online help at ***www.philips.com/support***

PHILIPS

General Information

Environmental Information

All unnecessary packaging has been omitted. The packaging has been made easy to separate into three materials: cardboard (box), polystyrene foam (buffer) and polyethylene (bags, protective foam sheet).

Your DVD player consists of materials which can be recycled and reused if disassembled by a specialised company. Please observe the local regulations regarding the disposal of packaging materials, exhausted batteries and old equipment.

"DTS", and "DTS Digital Surround" are registered trademarks of Digital Theater Systems, Inc.

The apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on apparatus.

For Customer Use:

Read carefully the information located at the rear of your DVD VIDEO player and enter below the Serial No. Retain this information for future reference.

Model No. DVP 3000K
Serial No. _____

Laser safety

This unit employs a laser. Due to possible eye injury, only a qualified service person should remove the cover or attempt to service this device.

NOTE:
PICTURES SHOWN MAYBE DIFFERENT BETWEEN COUNTRIES.

CAUTION
(WARNING LOCATION: ON THE BACKPLATE OF THE SET)

NEVER MAKE OR CHANGE CONNECTIONS WITH THE POWER SWITCHED ON.

Important Note:
Due to the numerous versions of new CD-Audio copy protection or enhanced CD-Audio protection recently available on certain discs, Philips is unable to guarantee that this DVD Player is fully compatible with such new discs. Should you have difficulty playing any such CD-Audio discs, kindly refer them to your CD-Audio disc retailer.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

LASER	
Type	Semiconductor laser GaAlAs
Wave length	650 nm (DVD) 780 nm (VCD/CD)
Output Power	7 mW (DVD) 10 mW (VCD/CD)
Beam divergence	60 degree

Index

English ---------- 6

中文(简体) ---------- 42

English

中文(简体)

01-41 DVP3000K_93_RC2 3 26/09/05, 9:52 AM

This product incorporates copyright protection technology that is protected by method claims of certain U.S. patents and other intellectual property rights owned by Macrovision Corporation and other rights owners. Use of this copyright protection technology must be authorized by Macrovision Corporation, and is intended for home and other limited viewing uses only unless otherwise authorized by Macrovision Corporation. Reverse engineering or disassembly is prohibited.

Manufactured under license from Dolby Laboratories. "Dolby", "Pro-Logic" and the double-D symbol are trademarks of Dolby Laboratories.

Due to the inconsistency of disc formats provided by various disc manufacturers, your DVD system may require a playability enhancement or upgrade. As DVD technology advances, these enhancements will become common and will be easy to complete.
Go to www.philips.com/support for software upgrade.

01-41 DVP3000K_93_RC2 4 26/09/05, 9:52 AM

Language Code

Abkhazian	6566
Afar	6565
Afrikaans	6570
Amharic	6577
Arabic	6582
Armenian	7289
Assamese	6583
Avestan	6569
Aymara	6589
Azerhaijani	6590
Bahasa Melayu	7783
Bashkir	6665
Belarusian	6669
Bengali	6678
Bihari	6672
Bislama	6673
Bokmål, Norwegian	7866
Bosanski	6683
Brezhoneg	6682
Bulgarian	6671
Burmese	7789
Castellano, Español	6983
Catalán	6765
Chamorro	6772
Chechen	6769
Chewa; Chichewa; Nyanja	7889
中文	9072
Chuang; Zhuang	9065
Church Slavic; Slavonic	6785
Chuvash	6786
Corsican	6779
Česky	6783
Dansk	6865
Deutsch	6869
Dzongkha	6890
English	6978
Esperanto	6979
Estonian	6984
Euskara	6985
Ελληνικά	6976
Faroese	7079
Français	7082
Frysk	7089
Fijian	7074
Gaelic; Scottish Gaelic	7168
Gallegan	7176
Georgian	7565
Gikuyu; Kikuyu	7573
Guarani	7178
Gujarati	7185
Hausa	7265
Herero	7290
Hindi	7273
Hiri Motu	7279
Hrwatski	6779
Ido	7379
Interlingua (International)	7365
Interlingue	7365
Inuktitut	7385
Inupiaq	7375
Irish	7165
Íslenska	7383
Italiano	7384
Ivrit	7269
Japanese	7465
Javanese	7486
Kalaallisut	7576
Kannada	7578
Kashmiri	7583
Kazakh	7575
Kernewek	7587
Khmer	7577
Kinyarwanda	8287
Kirghiz	7589
Komi	7586
Korean	7579
Kuanyama; Kwanyama	7574
Kurdish	7585
Lao	7679
Latina	7665
Latvian	7686
Letzeburgesch;	7666
Limburgan; Limburger	7673
Lingala	7678
Lithuanian	7684
Luxembourgish;	7666
Macedonian	7775
Malagasy	7771
Magyar	7285
Malayalam	7776
Maltese	7784
Manx	7186
Maori	7773
Marathi	7782
Marshallese	7772
Moldavian	7779
Mongolian	7778
Nauru	7865
Navaho; Navajo	7886
Ndebele, North	7868
Ndebele, South	7882
Ndonga	7871
Nederlands	7876
Nepali	7869
Norsk	7879
Northern Sami	8369
North Ndebele	7868
Norwegian Nynorsk;	7878
Occitan; Provencal	7967
Old Bulgarian; Old Slavonic	6785
Oriya	7982
Oromo	7977
Ossetian; Ossetic	7983
Pali	8073
Panjabi	8065
Persian	7065
Polski	8076
Português	8084
Pushto	8083
Russian	8285
Quechua	8185
Raeto-Romance	8277
Romanian	8279
Rundi	8278
Samoan	8377
Sango	8371
Sanskrit	8365
Sardinian	8367
Serbian	8382
Shona	8378
Shqip	8381
Sindhi	8368
Sinhalese	8373
Slovensky	8373
Slovenian	8376
Somali	8379
Sotho; Southern	8384
South Ndebele	7882
Sundanese	8385
Suomi	7073
Swahili	8387
Swati	8383
Svenska	8386
Tagalog	8476
Tahitian	8489
Tajik	8471
Tamil	8465
Tatar	8484
Telugu	8469
Thai	8472
Tibetan	6679
Tigrinya	8473
Tonga (Tonga Islands)	8479
Tsonga	8483
Tswana	8478
Türkçe	8482
Turkmen	8475
Twi	8487
Uighur	8571
Ukrainian	8575
Urdu	8582
Uzbek	8590
Vietnamese	8673
Volapuk	8679
Walloon	8765
Welsh	6789
Wolof	8779
Xhosa	8872
Yiddish	8973
Yoruba	8979
Zulu	9085

01-41 DVP3000K_93_RC2 5 26/09/05, 9:52 AM

English

Contents

Language Code 5

Introduction
Supplied accessories 8
Care and safety information 8

Connections
Connecting TV 9-10
- Using Composite Video jacks (CVBS) 9
- Using Component Video jacks (Pr Pb Y) ... 9
- Using an accessory RF modulator 10

Connecting the power cord 10
Optional: Connecting to a Multi-channel Receiver 11
- Receiver has a Dolby Digital or DTS decoder 11

Optional : Connecting to an Audio System 11
- Stereo system has Dolby Pro Logic or Right / Left Audio In jack 11

Optional: Connecting Digital AV Receiver 12
- Receiver has a PCM, Dolby Digital, or MPEG2 decoder 12

Functional Overview
Front and Rear Panels 13
Remote Control 14

Getting Started
Step 1: Inserting batteries into the Remote Control 15
- Using the Remote Control to operate the Player 15

Step 2: Setting up the TV 15-17
- Setting up Progressive Scan feature (for Progressive Scan TV only) 16
- To deactivate Progressive manually 17
- Selecting the colour system that corresponds to your TV 17

Step 3: Setting language preference 18
- Setting the OSD Language 18
- Setting the Audio, Subtitle and Disc menu language 18

Disc Operations
Playable Discs 19
Region Codes 19
Playing discs 19
Basic playback controls 20
Selecting various repeat/shuffle functions 20
- Repeat play mode 20
- Repeating a section within a chapter/track 20

Operations for video playback 21
- Using the Disc Menu 21
- Zooming in 21
- Resuming playback from the last stopped point 21
- Slow motion 21
- Using the OSD menu 21

Special DVD features 22
- Playing a Title 22
- Camera Angle 22
- Changing the Audio Language 22
- Subtitles 22

Special VCD & SVCD Features 22-23
- Playback Control (PBC) 22
- Preview Function (DVD/VCD) 23

Playing MP3/JPEG/Kodak Picture CD 24
- General Operation 24
- Selecting a folder and track/file 24

Special picture disc features 25
- Preview Function 25
- Zoom picture 25
- Playback with multi-angles 25
- Scan Effect 25

Karaoke Operations
Playing Karaoke discs 26
- General Operation 26
- Key setting 26
- Vocal 26
- Mode 26

01-41 DVP3000K_93_RC2 6 26/09/05, 9:53 AM

Contents

English

DVD Menu Options

General Setup menu 27-28
- Locking/Unlocking the disc for viewing ... 27
- Programming disc tracks 27-28
- OSD Language 28
- Screen Saver - turning on/off 28
- Sleep 28

Audio Setup Menu 29-31
- Analogue output 29
- Digital Audio Setup 29
- Sound Mode 30
- Speaker Setup 30
- CD Upsampling 30
- Night Mode - turning on/off 31

Video Setup Menu 31-33
- TV Type 31
- Setting the TV Display 32
- Progressive - turning on/off 32
- Picture Setting 33

Preference Page 34-36
- Audio, Subtitle, Disc Menu 34
- Restricting playback by Parental Control 34-35
- PBC 35
- MP3/JPEG Menu - turning on/off 35
- Changing the Password 36
- Restoring to original settings 36

Sound and Volume Controls

Setting the speakers' channels 37

Troubleshooting 38–39

Specifications 40

Glossary 41

01-41 DVP3000K_93_RC2 7 26/09/05, 9:53 AM

Introduction

Supplied accessories

Audio cable (white, red) / Composite video cable (yellow)



Remote Control and two AA batteries



Care and safety information

- **Power consumption**
  – When the system is switched to Standby mode, it is still consuming power. To disconnect the system from the power supply completely, remove the AC power plug from the wall jack.
- **Avoid high temperatures, moisture, water and dust**
  – Do not expose the player, batteries or discs to humidity, rain, sand or excessive heat (caused by heating equipment or direct sunlight.)
- **Avoid condensation problem**
  – The lens may cloud over when the player is suddenly moved from cold to warm surroundings, making it impossible to play a disc. Leave the player in the warm environment until the moisture evaporates.
- **Do not block the vents**
  – Do not operate the DVD Player in an enclosed cabinet, allow about 10 cm (4 inch) of free space all around the player for adequate ventilation.



- **Care of the cabinet**
  – Use a soft cloth slightly moistened with a mild detergent solution. Do not use a solution containing alcohol, spirits, ammonia or abrasives.
- **Finding a suitable location**
  – Place the player on a flat, hard, and stable surface.
- **Disc handling**
  – To clean a CD, wipe it in a straight line from the center towards the edge using a soft, lint-free cloth. A cleaning agent may damage the disc!



  – Write only on the printed side of a CDR(W) and only with a soft felt-tipped pen.
  – Handle the disc by its edge, do not touch the surface.

01-41 DVP3000K_93_RC2 8 26/09/05, 9:53 AM

English

Connecting TV





IMPORTANT!
– You only need to make one video connection from the following options, depending on the capabilities of your TV system.
– Connect the DVD system directly to the TV.

Using Composite Video jacks (CVBS)

1. Use the composite video cable (yellow) to connect the DVD Player's CVBS (VIDEO) jack to the video input jack (or labeled as A/V In, Video In, Composite or Baseband) on the TV *(cable supplied)*.
2. To hear the sound of this DVD Player through your TV, use the audio cables (white/red) to connect [FRONT (L/R)] jacks of the DVD Player to the corresponding AUDIO IN jacks on the TV *(cable supplied)*.

IMPORTANT!
– The progressive scan video quality is only possible when using Y Pb Pr and a progressive scan TV is required.

Using Component Video jacks (Y Pb Pr)

1. Use the component video cables (red/blue/green) to connect the DVD system's **Y Pb Pr** jacks to the corresponding Component video input jacks (or labeled as Y Pb Pr) on the TV *(cable not supplied)*.
2. To hear the sound of this DVD Player through your TV, use the audio cables (white/red) to connect [FRONT (L/R)] jacks of the DVD Player to the corresponding AUDIO IN jacks on the TV *(cable supplied)*.
3. Proceed to page 16 for detailed Progressive Scan set up.

01-41 DVP3000K_93_RC2 9 26/09/05, 9:53 AM

Connections

English



IMPORTANT!
– If your TV only has a single Antenna In jack (or labeled as 75 ohm or RF In,) you will need an RF modulator in order to view the DVD playback on the TV. See your electronics retailer or contact Philips for details on RF modulator availability and operations.

Using an accessory RF modulator

1. Use the composite video cable (yellow) to connect the DVD Player's CVBS (VIDEO OUT) jack to the video input jack on the RF modulator.
2. Use the RF coaxial cable (not supplied) to connect the RF modulator to your TV's RF jack.

Connecting the power cord



After everything is connected properly, plug in the AC power cord to the power outlet.
Never make or change any connections with the power switched on.

01-41 DVP3000K_93_RC2 10 26/09/05, 9:53 AM

English

Optional: Connecting to a Multi-channel Receiver



Receiver has a Dolby Digital or DTS decoder

1. Select one of the video connections (CVBS VIDEO IN or COMPONENT VIDEO IN) depending on the options available on your TV.
2. Connect the Audio Out Left and Right jack for Front and Rear speakers to the corresponding input sockets on your Receiver *(cable not supplied)*.
3. Connect the Audio Out for Center speaker and Subwoofer to the corresponding inputs on your Receiver *(cable not supplied)*.
4. Set the DVD Player's Analog Output to 'Multichannel' to enable playback of DVDs recorded in Multi-channel. *(see page 29 "Setting the analogue output").*

Helpful Hint:
– If the subwoofer is equipped with its own amplifier, the Subwoofer connection should be connected directly to the subwoofer.

Optional: Connecting to an Audio System



Stereo system has Dolby Pro Logic or Right / Left Audio In jack

1. Select one of the video connections (CVBS VIDEO IN or COMPONENT VIDEO IN) depending on the options available on your TV.
2. Use the audio cables (white/red) to connect [FRONT (L/R)] jacks of the DVD Player to the corresponding AUDIO IN jacks on the stereo system *(cable supplied)*.

01-41 DVP3000K_93_RC2 11 26/09/05, 9:53 AM

Connections

Optional: Connecting Digital AV Receiver



Receiver has a PCM, Dolby Digital, or MPEG2 decoder

1. Select one of the video connections (CVBS VIDEO IN or COMPONENT VIDEO IN) depending on the options available on your TV.
2. Connect the COAXIAL jack of the DVD Player to the corresponding Digital Audio In jack on your Receiver *(cable not supplied)*.
3. Set the DVD Player's Digital Output to PCM-ONLY or ALL depending on the capabilities of your Receiver *(see page 29 "Digital Output")*.

Helpful Hint:
– If the audio format of the Digital Output does not match the capabilities of your receiver, the receiver will produce a strong, distorted sound or no sound at all.

01-41 DVP3000K_93_RC2 12 26/09/05, 9:53 AM

English

Front and Rear Panels





Caution: Do not touch the inner pins of the jacks on the rear panel. Electrostatic discharge may cause permanent damage to the unit.

01-41 DVP3000K_93_RC2 13 26/09/05, 9:53 AM

English

Functional Overview

Remote Control



RETURN / TITLE
– To go back to previous menu / show title menu

DISC MENU
– Enters or exits the disc contents menu
– Switches on or off the playback control mode (for VCD version 2.0 only)

◄ ► ▲ ▼
– Selects an item in the menu/ fast forward/backward, slow forward/ reverse

OK
– Acknowledge menu selection

|◄◄
– To select previous chapter or track

STOP (■)
– To stop playback

PLAY (►)
– To start playback

PAUSE (II)
– To pause playback temporarily / frame-by-frame playback

REPEAT
– Selects various repeat modes

REPEAT (A-B)
– Repeats playback a specific section on a disc

PREVIEW
– To preview the content of a track or whole disc

MUTE
– Disables or enables sound output

POWER ⏻
– To switch the DVD player to standby mode or ON

0-9 numerical key pad
– Selects numbered items in a menu

DISPLAY
– Displays information on TV screen during playback

SYSTEM MENU
– Access or exit DVD Player's system menu

►►|
– To select next chapter or track

SUBTITLE
– To access subtitle language in disc menu

ANGLE
– Selects a DVD camera angle

ZOOM
– Enlarge a picture on the TV screen

AUDIO
– To access audio language in disc menu

KARAOKE
– To set MIC on or off

KEY
– To set key control

VOCAL
– Choose audio channels or karaoke methods

MODE
– To toggle between 'Vol', 'Echo' or 'Key'

01-41 DVP3000K_93_RC2 14 26/09/05, 9:53 AM

Step 1: Inserting batteries into the Remote Control



1. Open the battery compartment.
2. Insert two batteries type R06 or AA, following the indications (+ −) inside the compartment.
3. Close the cover.

Using the Remote Control to operate the Player

1. Aim the Remote Control directly at the remote sensor (IR) on the front panel.
2. Do not put any objects between the Remote Control and the DVD Player while operating the DVD Player.



CAUTION!
– Remove batteries if they are exhausted or if the Remote Control is not being used for a long time.
– Do not use old and new or different types of batteries in combination.
– Batteries contain chemical substances, so they should be disposed properly.

Step 2: Setting up the TV

IMPORTANT!
Make sure you have completed all the necessary connections. (See pages 9-10 "Connecting TV").

1. Turn on the TV and set to the correct video-in channel. You should see the DVD background screen on the TV.
2. Usually these channels are between the lowest and highest channels and may be called FRONT, A/V IN, or VIDEO. See your TV manual for more details.
   ➜ Or, you may go to channel 1 on your TV, then press the Channel down button repeatedly until you see the Video In channel.
   ➜ Or, the TV Remote Control may have a button or switch that chooses different video modes.
   ➜ Or, set the TV to channel 3 or 4 if you are using an RF modulator.
3. If you are using external equipment, (eg. audio system or receiver), turn it on and select the appropriate input source for the DVD Player output. Refer to the equipment owner's manual for detail.

01-41 DVP3000K_93_RC2 15 26/09/05, 9:53 AM

Getting Started

Setting up Progressive Scan feature (for Progressive Scan TV only)

The progressive scan display twice the number of frames per seconds than interlaced scanning (ordinary normal TV system). With nearly double the number of lines, progressive scan offers higher picture resolution and quality.

IMPORTANT!
Before enabling the progressive scan feature, you must ensure:

1) Your TV can accept progressive signals, a progressive scan TV is required.
2) You have connected the DVD player to your TV using Y Pb Pr (see page 9.)

1. Turn on your TV.
2. Turn off your TV progressive scan mode or turn on interlaced mode (refer to your TV user manual.)
3. Press **POWER** on the remote control to turn on the DVD player.
4. Select the correct Video Input channel. (See page 15).
   ➜ The DVD background screen appears on the TV.
5. Press **SYSTEM MENU**.
6. Press ▶ repeatedly to select {VIDEO SETUP PAGE}.



7. Select {PROGRESSIVE} to {ON}, then **OK** to confirm.
   ➜ The instruction menu appears on the TV.


ACTIVATING PROGRESSIVE SCAN:
1. ENSURE YOUR TV HAS PROGRESSIVE SCAN.
2. CONNECT USING YPBPR (GBR) VIDEO CABLE.
3. IF THERE IS DISTORTED PICTURE
WAIT 15 SECONDS FOR AUTO RECOVERY.
OK
Cancel

8. Press ◀ to highlight OK in the menu and press **OK** to confirm.

   There will be a distorted picture on your TV at this state until you turn on the progressive scan mode on your TV.

9. Turn on your TV progressive scan mode (refer to your TV user manual.)
   ➜ The below menu appears on the TV.



10. Press ◀ to highlight OK in the menu and press **OK** to confirm.
    ➜ The set up is complete now and you can start enjoy the high quality picture.

TIPS: To return to the previous menu, press ◀.
To remove the menu, press **SYSTEM MENU**.

01-41 DVP3000K_93_RC2 16 26/09/05, 9:53 AM

To deactivate Progressive manually

- **When the distorted screen still appears on the TV,** it may be due to the connected TV does not accept progressive signals, and progressive is set by mistake. You must reset the unit to interlace format.

1. **Turn off** your TV progressive scan mode or turn on to interlaced mode (refer to your TV user manual.)
2. Press **OPEN/CLOSE** on the DVD player to open the disc tray.
3. Press **numeric keypad '1'** on the remote control for few seconds.
   ➜ The DVD blue background screen will appear on the TV.

Selecting the colour system that corresponds to your TV

This DVD Player is compatible with both NTSC and PAL. In order for a DVD disc to play on this Player, the colour system of the Disc, the TV and the DVD Player should match.



1. Press **SYSTEM MENU**.
2. Press ▶ repeatedly to select {VIDEO SETUP PAGE}.
3. Press ▲ ▼ to highlight {TV TYPE}, then press ▶.
4. Press ▲ ▼ to highlight one of the options below:

   PAL – Select this if the connected TV is PAL system. It will change the video signal of a NTSC disc and output in PAL format.

   NTSC – Select this if the connected TV is NTSC system. It will change the video signal of a PAL disc (VCD only) and output in NTSC format.

   Multi – Select this if the connected TV is compatible with both NTSC and PAL (multi-system). The output format will be in accordance with the video signal of the disc.
5. Select an item and press **OK**.

Helpful Hints:
– Before changing the current TV Standard setting, ensure that your TV supports the 'selected TV Type' system.
– If there is no proper picture on your TV, wait for 15 seconds for auto recovery.


CHANGING PAL TO NTSC:
1. ENSURE THAT YOUR TV SUPPORTS NTSC STANDARD.
2. IF THERE IS DISTORTED PICTURE DISPLAYED ON THE TV, WAIT 15 SECONDS FOR AUTO RECOVERY.
OK
CANCEL
CONFIRM AGAIN TO USE NEW TV TYPE SETTING.
OK
CANCEL

TIPS: To return to the previous menu, press ◀.
To remove the menu, press **SYSTEM MENU**.

01-41 DVP3000K_93_RC2 17 26/09/05, 9:53 AM

Getting Started

Step 3: Setting language preference

You can select your preferred language settings. This DVD Player will automatically switch to the language for you whenever you load a disc.

Setting the OSD Language

The On-screen language for the system menu will remain as you set it, regardless of various disc languages.



1. Press **SYSTEM MENU**.
2. Press ▶ to select {GENERAL SETUP PAGE}.
3. Press ▲▼ to highlight {OSD LANGUAGE}, then press ▶.
4. Press ▲▼ to select a language and press **OK**.

Setting the Audio, Subtitle and Disc menu language

You can choose your own preferred language or soundtrack from audio, subtitles and disc menu languages. If the language selected is not available on the disc, the disc's default language will be used instead.



1. Press **STOP** twice then, press **SYSTEM MENU**.
2. Press ▶ repeatedly to select {PREFERENCE PAGE}.
3. Press ▲▼ to highlight one of the options below at a time, then press ▶.
   – 'Audio' (disc's soundtrack)
   – 'Subtitle' (disc's subtitles)
   – 'Disc Menu' (disc's menu)
4. Press ▲▼ to select a language and press **OK**.

   If the language you want is not in the list, then select {OTHERS}**,** then use the **numeric keypad (0-9)** on the remote to enter the 4-digit language code 'XXXX' (see page 5 "Language Code") and press **OK**.
5. Repeat steps 3~4 for other language settings.

TIPS: To return to the previous menu, press ◀.
To remove the menu, press **SYSTEM MENU**.

01-41 DVP3000K_93_RC2 18 26/09/05, 9:53 AM

IMPORTANT!
– If the inhibit icon (ø) appears on the TV screen when a button is pressed, it means the function is not available on the current disc or at the current time.
– Depending on the DVD or VIDEO CD, some operations may be different or restricted.
– Do not push on the disc tray or put any objects other than disc on the disc tray. Doing so may cause the disc player malfunction.

Playable Discs

Your DVD Player will play:
– Digital Video Discs (DVDs)
– Video CDs (VCDs)
– Super Video CDs (SVCDs)
– Digital Video Discs + Recordable[Rewritable] (DVD+R[W])
– Compact Discs (CDs) and CDDA
– MP3 discs, picture (Kodak, JPEG) files on CD-R(W).
  – JPEG/ISO 9660 format
  – Maximum 30 characters display.
  – Supported sampling frequencies : 32 kHz, 44.1 kHz, 48 kHz (MPEG-1) 16 kHz, 22.05 kHz, 24 kHz (MPEG-2)
  – Supported Bit-rates : 32~256 kbps (MPEG-1), 8~160 kbps (MPEG-2) variable bitrates

Region Codes

DVD discs must be labeled for ALL regions or Region 6 in order to play on this Player. You cannot play Discs that are labeled for other regions.

Helpful Hints:
– It may not be possible to play CD-R/RW or DVD-R/RW in all cases due to the type of disc or condition of the recording.
– If you are having trouble playing a certain disc, remove the disc and try a different one. Improper formatted disc will not play on this DVD Player.

Playing discs

1. Connect the power cords of the DVD Player and TV (and any optional stereo or AV receiver) to a power outlet.
2. Turn on the TV power and set to the correct Video In channel. (See page 15 "Setting up the TV").
3. Press **STANDBY-ON** on the DVD Player front panel.
   ➜ You should see the Philips DVD background screen on the TV.
4. Press **OPEN/CLOSE ≜** button to open the disc tray and load in a disc, then press the same button again to close the disc tray.
   ➜ Make sure the label side is facing up. For double-sided discs, load the side you want to play facing up.
5. Playback will start automatically. If not press **PLAY ►**.
   ➜ If a disc menu appears on the TV, see page 21 "Using the Disc Menu".
   ➜ If the disc is locked by parental control, you must enter your six-digit password. (See page 34-35).

TIPS: The operating features described here might not be possible for certain discs. Always refer to the instructions supplied with the discs.

01-41 DVP3000K_93_RC2 19 26/09/05, 9:53 AM

Disc Operations

Basic playback controls

Unless otherwise stated, all operations described are based on Remote Control use.

Pausing playback

1. During playback, press **PAUSE II**.
   ➜ Playback will pause and sound will be muted.
2. To resume normal playback, press **PLAY ►**.

Selecting track/chapter

- Press |◄◄ / ►►| or use the numeric keypad (0-9) to key in a track/chapter number.
  ➜ If repeat mode is active, pressing |◄◄ / ►►| will replay the same track/chapter.

Searching backward/forward

- Press ◄ / ►, then press **PLAY ►** to resume normal playback.
  ➜ While searching, pressing ◄ / ► repeatedly again will decrease/increase the search speed.

Stopping playback

- Press ■.

Selecting various repeat/shuffle functions

Repeat play mode

- While playing a disc, press **REPEAT** continuously to choose a 'Play Mode'.

CHAPTER (DVD)
– to repeat playback of the current chapter.

TRACK/TITLE (CD/SVCD/VCD/DVD)
– to repeat playback of the current track (CD/SVCD/VCD)/title (DVD).

ALL
– to repeat playback of all the disc and all the programmed tracks.

SHUFFLE
– to playback at random order.

OFF
– to cancel the repeat mode.

Helpful Hint:
– *For VCD, repeat playback is not possible if the PBC mode is switched on.*

Repeating a section within a chapter/track

1. While playing a disc, press **REPEAT A-B** at your chosen starting point.
2. Press **REPEAT A-B** again at your chosen end point.
   ➜ The section will now repeat continuously.
3. To exit the sequence, press **REPEAT A-B**.

TIPS: The operating features described here might not be possible for certain discs. Always refer to the instructions supplied with the discs.

01-41 DVP3000K_93_RC2 20 26/09/05, 9:53 AM

Operations for video playback (DVD/VCD/SVCD)

Using the Disc Menu

Depending on the disc, a menu may appear on the TV screen once you load in the disc.

To select a playback feature or item

- Use ◄►▲▼ keys or **numeric keypad (0-9)** on the remote, then press **OK** to start playback.

To access or remove the menu

- Press **DISC MENU** on the remote.

Zooming in

This function allows you to enlarge the picture on the TV screen and to pan through the enlarged picture.

1. During playback, press **ZOOM** repeatedly to display the picture with different scales.
   ➜ Use ◄►▲▼ keys to pan through the enlarged picture.
   ➜ Playback will continue.
2. Press **ZOOM** repeatedly to return to the original size.

Resuming playback from the last stopped point

Resume playback of the last 5 discs is possible, even if the disc was ejected or the power switched off.

- Load one of the last 5 discs.
- Press **PLAY** ► and the disc will be played back from the last point.

To cancel resume mode

- In stop mode, press **STOP** ■ again.

Slow Motion

1. Press ▲▼ during playback to select the required speed: 1/2, 1/4, 1/8 or 1/16 (backward or forward).
   ➜ Sound will be muted.
2. To return to normal speed, press **PLAY** ►.

Helpful Hint:

– *Slow reverse is not possible on VCDs.*

Using the OSD menu

OSD menu shows the disc playback information (for example, title or chapter number, elapsed playing time, audio/ subtitle language), a number of operations can be done without interrupting disc playback.

1. During playback, press **DISPLAY**.
   ➜ A list of available disc information appears on the TV screen.

2. Press ▲▼ to view the information and press **OK** to access.
3. Press ► or **OK** to select an option.
4. Use the **numeric keypad (0-9)** to input the number/time or press ▲▼ to make the selection, then press **OK** to confirm.
   ➜ Playback will change to the chosen time or to the selected title/chapter/ track.

TIPS: The operating features described here might not be possible for certain discs. Always refer to the instructions supplied with the discs.

01-41 DVP3000K_93_RC2 21 26/09/05, 9:54 AM

Disc Operations

Special DVD Features

Playing a Title

1. Press **DISC MENU**.
   ➜ The disc menu appears on the TV screen.
2. Use ▲ ▼ ◀ ▶ keys or **numeric keypad (0-9)** to select a play option.
3. Press **OK** key to confirm.

Camera Angle

- Press **ANGLE** repeatedly to select different desired angle.

Changing the Audio Language

For DVD

- Press **AUDIO** repeatedly to select different audio languages.

Changing the Audio Channel

For VCD/CD

- Press **AUDIO** to select the available audio channels provided by the disc (MONO LEFT, MONO RIGHT, MIX-MONO, STEREO).

Subtitles

- Press **SUBTITLE** repeatedly to select different subtitle languages.

Special VCD & SVCD Features

Playback Control (PBC)

For VCD with Playback Control (PBC) feature (version 2.0 only)

- Press **DISC MENU** to toggle between 'PBC ON' and 'PBC OFF'.
  ➜ If you select 'PBC ON', the disc menu (if available) will appear on the TV.
  ➜ Use the |◀◀ / ▶▶| or the numeric keypad (0-9) to select a play option.
- During playback, pressing **RETURN/ TITLE** will return to the menu screen (if PBC is on).

If you want to skip the index menu and playback directly from the beginning,

- Press **DISC MENU** key on the remote control to switch to PBC off.

TIPS: The operating features described here might not be possible for certain discs. Always refer to the instructions supplied with the discs.

01-41 DVP3000K_93_RC2 22 26/09/05, 9:54 AM

Preview Function (DVD/VCD)

The preview function allows you to reduce the picture of 6 tracks enough to display in a full screen.

1. Press **PREVIEW**.
   ➜ The preview menu appears on the TV screen.



(DVD example)



(Video CD example)

2. Press ▲▼ to select the **PREVIEW** type, then press **OK**.
   ➜ The picture of each segment will appear on the screen.



(example for 6 thumbnail pictures display)

3. Press ▲▼◀▶ to select a track and input your selected track number using the numeric keypad (0-9), then press **OK**.
   ➜ Playback will start automatically on the selected track.

- For CDDA (Musical CD)
  ➜ Press **PREVIEW** to listen to the first 6 seconds of each sound track in the disc.

TIPS: The operating features described here might not be possible for certain discs. Always refer to the instructions supplied with the discs.

01-41 DVP3000K_93_RC2 23 26/09/05, 9:54 AM

Disc Operations

Playing MP3/JPEG/Kodak Picture CD

IMPORTANT!
You have to turn on your TV and set to the correct Video In channel. (See page 15 "Setting up the TV").

General Operation

1. Load a disc.
   ➜ The disc reading time may exceed 30 seconds due to the complexity of the directory/file configuration.
   ➜ The data disc menu appears on the TV screen.
2. Playback will start automatically. If not press **PLAY ►** (for Kodak Picture disc only).



Selecting a folder and track/file

1. Press ▲ ▼ to select the folder and press **OK** to open the folder.
2. Press ▲ ▼ to select a track/file.
3. Press |◄◄ / ►►| to go to previous/next page.
4. Press **OK** to confirm.
   ➜ Playback will start from the selected file to the end of the folder.

- To select another folder from the current disc, press ◄ to return to the root menu, then press ▲ ▼ to make your selection and press **OK** to confirm.

During playback, you can;

- Press |◄◄ / ►►| to select another track/file in the current folder.
- Press **REPEAT** continuously to access different 'Play Mode'.
  ➜ SINGLE: play the selected file once, then return to the menu.
  ➜ FOLDER: files will be played back once.
  ➜ REPEAT ONE: one file being played repeatedly.
  ➜ REPEAT FOLDER: all files in one folder being played repeatedly.
  ➜ SHUFFLE: all files in the current folder being played at random order.
- Press **II** to pause playback.

Helpful Hints:
– It may not be possible to play certain MP3/JPEG disc due to the configuration and characteristics of the disc or condition of the recording.
– It is normal to experience an occasional "skip" while listening to your MP3 disc.
– For multi-session discs with different formats, only the first session will be available.

TIPS: The operating features described here might not be possible for certain discs. Always refer to the instructions supplied with the discs.

01-41 DVP3000K_93_RC2 24 26/09/05, 9:54 AM

Special picture disc features

IMPORTANT!
You have to turn on your TV and set to the correct Video In channel. (See page 15 "Setting the TV").

- Load a Picture disc (Kodak Picture CD, JPEG).
  ➜ For Kodak disc, the slide show will begin.
  ➜ For JPEG disc, the picture menu appears on the TV screen. Press **PLAY ►** to start the slide-show playback.

Preview Function (JPEG)

This function shows the content of the current folder or the whole disc.

1. Press **PREVIEW** during playback.
   ➜ 12 thumbnail pictures will appear on the TV screen.

2. Press I◄◄ / ►►I to display the other pictures on the previous/next page.
3. Use ◄►▲▼ to highlight one of the picture and press **OK** to start playback.
4. Press **DISC MENU** to return to picture disc menu.

Zoom picture

1. During playback, press **ZOOM** repeatedly to display the picture with different scales.
2. Use ◄►▲▼ keys to view the zoomed picture.

Playback with multi-angles

- During playback, press ▲▼◄► to rotate the picture on the TV screen.
  ▲: flip the picture vertically
  ▼: flip the picture horizontally
  ◄: rotate the picture anti-clockwise
  ►: rotate the picture clockwise

Scan Effect

- Press **ANGLE** repeatedly to choose different scan effect.
  ➜ Various scan effect appears on the top left hand corner on the TV screen.

TIPS: The operating features described here might not be possible for certain discs. Always refer to the instructions supplied with the discs.

01-41 DVP3000K_93_RC2 25 26/09/05, 9:54 AM

Karaoke Operations

Playing Karaoke discs

IMPORTANT!
You have to turn on your TV and set to the correct Video In channel. (See page 15 "Setting up the TV").

General Operation

1. Connect a microphone (not supplied) to MIC on the side panel of the DVD player.



2. Press **KARAOKE** repeatedly.
   ➜ 'MIC ON/OFF' appears on the TV screen.
3. Load a karaoke disc and press **PLAY ►**.
4. Adjust the microphone volume using **MIC LEVEL** button on the side panel of the DVD player.

Helpful Hint:
– Before connecting the microphone, set the microphone volume to the minimum level to prevent howling.

Key setting

- This function allows you to adjust the key tone level to match with your vocal.
- Press **KEY** and use ◄► to adjust the pitch to adopt your voice.

Vocal

- You can fade out the original vocal from a karaoke disc.
- Press **VOCAL** repeatedly to choose different audio modes.

Helpful Hint:
– This function and on screen display depends on the availability of the disc.

Mode

- Press **MODE** repeatedly to toggle between 'Vol', 'Echo' or 'Key'.

1. When 'Vol' is selected, press ◄► to adjust the vocal value between 0 and 20.
2. When 'Echo' is selected, press ◄► to adjust the echo value between 0 and 20.
3. When 'Key' is selected, press ◄► to adjust the pitch value between -16 and 16.

01-41 DVP3000K_93_RC2 26 26/09/05, 9:54 AM

DVD Setup Menu Options

This DVD Player setup is carried out via the TV, enabling you to customise the DVD Player to suit your particular requirements.

General Setup menu

1. In disc mode, press **SYSTEM MENU**.
2. Press ◄► to select 'General Setup' icon.
3. Press **OK** to confirm.



Locking/Unlocking the disc for viewing

Not all discs are rated or coded by the disc maker. You can prevent a specific disc from playing by locking the disc. Up to 40 discs can be locked.

1. In 'GENERAL SETUP PAGE', press ▲▼ to highlight {DISC LOCK}, then press ►.

LOCK
Select this to block the playback of the current disc. Subsequent access to a locked disc requires six-digit password. The default password is '136 900' (see page 36 "Changing the password").

UNLOCK
Select this to unlock the disc and allow future playback.

2. Press ▲ ▼ to select a setting, then press **OK** to confirm your selection.

Programming disc tracks (not for Picture CD/MP3)

You can play the contents of the disc in the order you want by programming the tracks to be played. Up to 20 tracks can be stored.

1. In 'GENERAL SETUP PAGE', press ▲▼ to highlight {PROGRAM}, then press ► to select {INPUT MENU}.
2. Press **OK** to confirm.



To input your favourite tracks/chapter

3. Use the **numeric keypad (0-9)** to enter a valid track/chapter number.
4. Use ◄► ▲▼ keys to move the cursor to the next position.
   → If the track number is more than ten, press ►►| to open the next page and proceed with programming or,
   → Use ◄► ▲▼ keys to highlight {NEXT} on the programme menu, then press **OK**.
5. Repeat steps 3~4 to input another track/chapter number.

TIPS: To return to the previous menu, press ◄.
To remove the menu, press **SYSTEM MENU**.

01-41 DVP3000K_93_RC2 27 26/09/05, 9:54 AM

DVD Setup Menu Options

If you want to remove a track

6 Use ◄► ▲ ▼ keys to move the cursor to the track you want to remove.

7 Press **OK** to remove this track from the programme menu.

To start programme playback

8 Use ◄► ▲ ▼ keys to highlight {START} on the programme menu, then press **OK**.
➜ Playback will start with the selected tracks under the programmed sequence.

To exit programme playback

9 Use ◄► ▲ ▼ keys to highlight {EXIT} on the programme menu, then press **OK**.

OSD Language

This menu contains various language options for display language on the screen. For details, see page 18.

Screen Saver - turning on/off

The screen saver will help to prevent your TV display device from becoming damaged.

1 In 'GENERAL SETUP PAGE', press ▲ ▼ to highlight {SCREEN SAVER}, then press ►.

ON
Select this if you wish to turn off the TV screen when disc playback is stopped or paused for more than 15 minutes.

OFF
Select this to disable the screen saver function.

2 Press ▲ ▼ to select a setting, then press **OK** to confirm your selection.

Sleep

Sleep function allows you to turn off the DVD Player automatically after a preset time.

1 In 'GENERAL SETUP PAGE', press ▲ ▼ to highlight {SLEEP}, then press ►.

15 Mins
Turn off the DVD Player after 15 minutes.

30 Mins
Turn off the DVD Player after 30 minutes.

45 Mins
Turn off the DVD Player after 45 minutes.

60 Mins
Turn off the DVD Player after 60 minutes.

OFF
Turn off the sleep function.

2 Press ▲ ▼ to select a setting, then press **OK** to confirm your selection.

TIPS: To return to the previous menu, press ◄.
To remove the menu, press **SYSTEM MENU**.

01-41 DVP3000K_93_RC2 28 26/09/05, 9:54 AM

English

Audio Setup Menu

1. In disc mode, press **SYSTEM MENU**.
2. Press ◄► to select 'Audio Setup' icon.
3. Press **OK** to confirm.



Analog Output

Set Analogue Output to match your DVD Player's playback capability.

1. In 'AUDIO SETUP PAGE', press ▲▼ to highlight {ANALOG OUTPUT}, then press ►.

Stereo
Select this option when output delivers sound from only the two front speakers.

LT/RT
Select this option if your DVD Player is connected to a Dolby Pro Logic decoder.

V SURR
Allows the DVD player to use virtual surround sound effects.

Multichannel
Select this to enable Multi-channel output.

2. Press ▲▼ to select a setting, then press **OK** to confirm your selection.

Digital Audio Setup

The options included in Digital Audio Setup are: 'Digital Output' and 'LPCM Output'.

1. In 'AUDIO SETUP PAGE', press ▲▼ to highlight {DIGITAL AUDIO SETUP}, then press ►.
2. Press the ▲▼ keys to highlight an option.
3. Enter its submenu by pressing ►.
4. Press ▲▼ to select a setting, then press **OK** to confirm your selection.

Digital Output
Set the Digital output according to your optional audio equipment connection.
➜ **All**: If you have connected your DIGITAL AUDIO OUT to a multi-channel decoder/receiver.
➜ **PCM Only**: Only if your receiver is not capable of decoding multi-channel audio.

Helpful Hints:
– *If DIGITAL OUTPUT is set to 'All', all audio settings except MUTE are invalid.*

LPCM Output

If you connect the DVD Player to a PCM compatible receiver via the digital terminals, such as coaxial or optical etc, you may need to adjust 'LPCM Output'. Discs are recorded at a certain sampling rate. The higher the sampling rate, the better the sound quality.

➜ **48k**: Playback a disc recorded at the sampling rate of 48kHz.
➜ **96k**: Playback a disc recorded at the sampling rate of 96kHz that can only be achieved in Stereo-Classic (Flat) mode.

Helpful Hint:
– *LPCM Output can be selected only when PCM Only is activated.*

TIPS: To return to the previous menu, press ◄.
To remove the menu, press **SYSTEM MENU**.

01-41 DVP3000K_93_RC2 29 26/09/05, 9:54 AM

DVD Setup Menu Options

Sound Mode

The options included in Sound Mode Setup are: '3D', 'Movie Mode' and 'Music Mode'.

1. In 'AUDIO SETUP PAGE', press ▲ ▼ to highlight {SOUND MODE}, then press ▶.
2. Press the ▲ ▼ keys to highlight an option.
3. Enter its submenu by pressing ▶.
4. Press ▲ ▼ to select a setting, then press **OK** to confirm your selection.

3D
This function provides a virtual surround sound experience using just two speakers.
➜ **Off, Living Room, Hall, Arena and Church**

Movie Mode
Select a Sound Mode that matches the type of music you are playing. These preset Sound Modes adjust the frequency bands of the video to enhance your favourite movie sound track.
➜ **Off, Sci-Fic, Action, Drama and Concert**

Music Mode
Select a Sound Mode that matches the type of music you are playing. These preset Sound Modes adjust the frequency bands of the audio to enhance your favourite music.
➜ **Off, Digital, Rock, Classic and Jazz**

Speaker Setup

This menu contains setup options for your audio output which makes the speaker setup system reproduce high quality surround sound. For details, see page 37.

CD Upsampling

This feature allows you to convert your music CD to a higher sampling rate using sophisticated digital signal processing for better sound quality. If you have activated the upsampling, the player will automatically switch to stereo mode.

1. In 'AUDIO SETUP PAGE', press ▲ ▼ to highlight {CD UPSAMPLING}, then press ▶.

OFF
Select this to disable CD-upsampling.

88.2 kHz (X2)
Select this to convert the sampling rate of the CDs twice higher than the original.

176.4 kHz (X4)
Select this to convert the sampling rate of the CDs four times higher than the original.

2. Press ▲ ▼ to select a setting, then press **OK** to confirm your selection.

Helpful Hint:
– *CD upsampling feature is only applicable to stereo output setting.*

TIPS: To return to the previous menu, press ◀.
To remove the menu, press **SYSTEM MENU**.

01-41 DVP3000K_93_RC2 30 26/09/05, 9:54 AM

Night Mode - turning on/off

In this mode, the high volume outputs are softened and low volume outputs are brought upward to an audible level. It is useful for watching your favourite action movie without disturbing others at night.

1. In 'AUDIO SETUP PAGE', press ▲▼ to highlight {NIGHT MODE}, then press ▶.

   ON
   Select this to level out the volume. This feature is only available for movies with Dolby Digital mode.

   OFF
   Select this when you want to enjoy the surround sound with its full dynamic range.

2. Press ▲▼ to select a setting, then press **OK** to confirm your selection.

Video Setup Menu

1. In disc mode, press **SYSTEM MENU**.
2. Press ◀▶ to select 'Video Setup' icon.
3. Press **OK** to confirm.



TV Type

This menu contains the options for selecting the colour system that matches the connected TV. For details, see page 17.

TIPS: To return to the previous menu, press ◀.
To remove the menu, press **SYSTEM MENU**.

01-41 DVP3000K_93_RC2 31 26/09/05, 9:54 AM

DVD Setup Menu Options

Setting the TV Display

Set the aspect ratio of the DVD Player according to the TV you have connected. The format you select must be available on the disc. If it is not, the setting for TV display will not affect the picture during playback.

1. In 'VIDEO SETUP PAGE', press ▲ ▼ to highlight {TV DISPLAY}, then press ▶.
2. Press ▲ ▼ to highlight one of the options below:



4:3 PAN SCAN – Select this if you have a normal TV and want both sides of the picture to be trimmed or formatted to fit your TV screen.

4:3 LETTER BOX – Select this if you have a normal TV. In this case, a wide picture with black bands on the upper and lower portions of the TV screen will be displayed.



16:9 – Select this if you have a wide-screen TV.

3. Select an item and press **OK**.

Progressive - turning on/off

In the progressive scan mode, you can enjoy the high quality picture with less flickers. It only works when you have connected the DVD player's Y Pb Pr jacks to your TV that supports the progressive video input. Otherwise, the a distorted picture will appear on the TV. For proper progressive scan set up, see page 16.

1. In 'VIDEO SETUP PAGE', press ▲ ▼ to highlight {PROGRESSIVE}, then press ▶.

OFF
To disable Progressive Scan function.

ON
To enable Progressive Scan function.

2. Press ▲ ▼ to select a setting, then press **OK** to confirm your selection.
➜ Follow the instructions shown on the TV to confirm the selection (if any).
➜ If a distorted picture appears on the TV screen, wait for 15 seconds for auto recovery.

TIPS: To return to the previous menu, press ◀.
To remove the menu, press **SYSTEM MENU**.

01-41 DVP3000K_93_RC2 32 26/09/05, 9:54 AM

Picture Setting

This DVD Player provides three predefined sets of picture colour settings and one personal setting which you can define yourself.

1. In 'VIDEO SETUP PAGE', press ▲ ▼ to highlight {PICTURE SETTING}, then press ▶.

STANDARD
Select this for standard picture setting.

BRIGHT
Select this will make the TV picture brighter.

SOFT
Select this will make the TV picture softer.

PERSONAL
Select this to personalise your picture colour by adjusting the brightness, contrast, tint and colour (saturation).

2. Press ▲ ▼ to select a setting, then press **OK** to confirm your selection.

3. If you select {PERSONAL}, then proceed to steps 4~7.
➜ The 'PERSONAL PICTURE SETUP' menu appears.



4. Press ▲ ▼ to highlight one of the following options.

BRIGHTNESS
Increase the value will brighten the picture or vice versa. Choose zero (0) for average setting.

CONTRAST
Increase the value will sharpen the picture or vice versa. Choose zero (0) to balance the contrast.

TINT
Increase the value will darken the picture or vice versa. Choose zero (0) for average setting.

COLOUR
Increase the value will enhance the colour in your picture or vice versa. Choose zero (0) to balance the colour.

5. Press ◀ ▶ to adjust the setting that best suit your personal preference.
6. Repeat steps 4~5 for adjusting other colour features.
7. Press **OK** to confirm.

TIPS: To return to the previous menu, press ◀.
To remove the menu, press **SYSTEM MENU**.

DVD Setup Menu Options

Preference Page

1. Press ■ twice to stop playback (if any), then press **SYSTEM MENU**.
2. Press ◄► to select the 'Preference Setup' icon.
3. Press **OK** to confirm.



Audio, Subtitle, Disc Menu

These menus contain various language options for audio, subtitle and disc menu which may be recorded on the DVD. For details, see page 17.

Restricting playback by Parental Control

Some DVDs may have a parental level assigned to the complete disc or to certain scenes on the disc. This feature lets you set a playback limitation level. The rating levels are from 1 to 8 and are country dependent. You can prohibit the playing of certain discs that are not suitable for your children or have certain discs played with alternative scenes.

1. In 'PREFERENCE PAGE', press ▲▼ to highlight {PARENTAL}, then press ►.



TIPS: To return to the previous menu, press ◄.
To remove the menu, press **SYSTEM MENU**.

01-41 DVP3000K_93_RC2 34 26/09/05, 9:54 AM

Restricting playback by Parental Control - cont'd

2 Press ▲ ▼ to highlight a rating level for the disc inserted and press **OK**.
➜ To disable Parental controls and have all Discs play, select {8 ADULT}.

3 Use the **numeric keypad (0-9)** to enter the six-digit password (see page 36 "Changing the password").
➜ DVDs that are rated above the level you selected will not play unless you enter your six-digit password.

Helpful Hints:
– *VCD, SVCD, CD have no level indication, so parental control function has no effect on these type of discs. This applies to most illegal DVD discs.*
– *Some DVDs are not encoded with a rating though the movie rating may be printed on the Disc cover. The rating level feature does not work for such Discs.*

PBC

You can set the PBC to ON or OFF. This feature is available only on Video CD 2.0 with playback control (PBC) feature. For details, see page 22.

MP3/JPEG Menu - turning on/off

MP3/JPEG Navigator can be set only if the disc is recorded with menu. It allows you to select different display menus for easy navigation.

1 In 'PREFERENCE PAGE', press ▲ ▼ to highlight {MP3/JPEG NAV}, then press ▶.

WITHOUT MENU
Select this to display all the files contained in the MP3/Picture CD.

WITH MENU
Select this to display only the folder menu of the MP3/Picture CD.

2 Press ▲ ▼ to select a setting, then press **OK** to confirm your selection.

TIPS: To return to the previous menu, press ◀.
To remove the menu, press **SYSTEM MENU**.

01-41 DVP3000K_93_RC2 35 26/09/05, 9:54 AM

DVD Setup Menu Options

Changing the Password

The same password is used for both Parental Control and Disc Lock. Enter your six-digit password when prompted on the screen. The default password is 136 900.

1. In 'PREFERENCE PAGE', press ▲ ▼ to highlight {PASSWORD}.



2. Use the **numeric keypad (0-9)** to enter your old six-digit password.
   ➜ When doing this for the first time, key in '136 900'.
   ➜ If you forget your old six-digit password, key in '136 900'.
3. Enter the new six-digit password.
4. Enter the new six-digit password a second time to confirm.
   ➜ The new six-digit password will now take effect.
5. Press **OK** to confirm.

Restoring to original settings

Setting the DEFAULT function will reset all options and your personal settings to the factory defaults, except your password for Parental Control and Disc Lock.

1. In 'PREFERENCE PAGE', press ▲ ▼ to highlight {DEFAULT}, then press ▶ to select {RESET}.
2. Press **OK** to confirm.
   ➜ All settings will now reset to factory defaults.

TIPS: To return to the previous menu, press ◀.
To remove the menu, press **SYSTEM MENU**.

01-41 DVP3000K_93_RC2 36 26/09/05, 9:54 AM

English

Setting the speakers' channels

You can adjust the delay times (centre and surround only) and volume level for individual speakers. These adjustments let you optimise the sound according to your surroundings and setup.

IMPORTANT!
The speaker settings only available on Multi-channel audio outputs.

1. Press **STOP** then, press **SYSTEM MENU**.
2. Press ▶ repeatedly to select {AUDIO SETUP PAGE}.
3. Press ▲▼ to highlight {SPEAKER SETUP}, then press ▶.



4. Enter its submenu by pressing ▶.
5. Press ▲▼ to highlight one of the options below at a time, then press ▶.

{FRONT SPEAKERS, CENTER SPEAKER, REAR SPEAKERS}
OFF – when no speaker is connected.
LARGE – when connected speakers can produce low frequency signals below 120Hz.
SMALL – when connected speakers cannot produce low frequency signals below 120Hz.

{SUBWOOFER}
ON – when a subwoofer is connected.
OFF – when no subwoofer is connected.

{SPEAKER VOLUME} – Volume level setting for individual speakers (-6dB ~ +6dB).



{SPEAKER DELAY} – Delay times setting in relation to the listening position/ distance for centre and surround speakers (1m ~ 10m).



6. Press ◀▶ to adjust the setting that best suit your surround sound needs.
7. Press **OK** to confirm.

Helpful Hints:
– Use the longer delay time settings when the rear speakers are closer to the listener than the front speakers.

TIPS: To return to the previous menu, press ◀.
To remove the menu, press **SYSTEM MENU**.

01-41 DVP3000K_93_RC2 37 26/09/05, 9:54 AM

Troubleshooting

English

WARNING
Under no circumstances should you try to repair the system yourself, as this will invalidate the warranty. Do not open the system as there is a risk of electric shock.

If a fault occurs, first check the points listed below before taking the system for repair. If you are unable to remedy a problem by following these hints, consult your dealer or Philips for help.

Problem	Solution
No power	– Check if the AC power cord is properly connected. – Press the STANDBY ON on the front of the DVD system to turn on the power.
No picture	– Refer to your TV's manual for correct Video In channel selection. Change the TV channel until you see the DVD screen. – Check if the TV is switched on. – If the progressive scan feature is activated but the connected TV does not support progressive signals or the cables are not connected accordingly, see page 16 for proper progressive scan set up or deactivate the progressive scan feature as below: 1) Turn off your TV progressive scan mode or turn on to interlaced mode. 2) Press OPEN/CLOSE to open the disc tray. 3) Press numeric keypad '1' on the remote control for few seconds.
Distorted picture	– Sometimes a small amount of picture distortion may appear depending on the disc being played back. This is not a malfunction.
Completely distorted picture or black/white picture with DVD	– Connect DVD Player directly to the TV. – Make sure the disc is compatible with the DVD/ Player. – Ensure that the DVD Player's TV Type is set to match that of the Disc and your TV.
No sound or distorted sound	– Adjust the volume. – Check that the speakers are connected correctly.
No audio at digital output	– Check the digital connections. – Check if your receiver can decode MPEG-2 or DTS and if not, please make sure the digital output is set to PCM. – Check if the audio format of the selected audio language matches your receiver capabilities.

Visit us at www.philips.com/support for service support

01-41 DVP3000K_93_RC2 38 26/09/05, 9:54 AM

Troubleshooting

Problem	Solution
Disc can't be played	– The DVD+R/CD-R must be finalised. – Ensure the disc label is facing up. – Check if the disc is defective by trying another disc. – Region code incorrect.
Picture freezes momentarily during playback	– Check the disc for fingerprints/scratches and clean with a soft cloth wiping from centre to edge.
No return to start-up screen when disc is removed	– Reset the unit by switching the player off, then on again.
The player does not respond to the Remote Control	– Aim the Remote Control directly at the sensor on the front of the player. – Reduce the distance to the player. – Replace the batteries in the Remote Control. – Re-insert the batteries with their polarities (+/– signs) as indicated.
Buttons do not work	– To completely reset the player, unplug the AC cord from the AC outlet for 5-10 seconds.
Player does not respond to some operating commands during playback.	– Operations may not be permitted by the disc. Refer to the instructions of the disc jacket.
DVD Player cannot read CDs/DVDs	– Use a commonly available cleaning CD/DVD to clean the lens before sending the DVD Player for repair.
Menu items cannot be selected	– Press STOP twice before selecting System Menu. – Depending on the disc availability, some menu items cannot be selected.
Unable to select Progressive Scan on/off	– Check that the output of the video signal is switch to 'YUV'.

Visit us at www.philips.com/support for service support

01-41 DVP3000K_93_RC2 39 26/09/05, 9:54 AM

English

Specifications

TV STANDARD (PAL/50Hz) (NTSC/60Hz)

Number of lines	625	525
Playback	Multistandard	(PAL/NTSC)

VIDEO PERFORMANCE

Video DAC	12 bit, 108 MHz
YPbPr	0.7 Vpp — 75 ohm
Video Output	1Vpp — 75 ohm

VIDEO FORMAT

Digital Compression	MPEG 2 for DVD,SVCD MPEG 1 for VCD

DVD	**50Hz**	**60Hz**
Horiz. resolution	720 pixels	720 pixels
Vertical resolution	576 lines	480 lines
VCD	**50Hz**	**60Hz**
Horiz. resolution	352 pixels	352 pixels
Vertical resolution	288 lines	240 lines

AUDIO FORMAT

Digital	MPEG/ AC-3/ PCM	compressed Digital 16, 20, 24 bits fs, 44.1, 48, 96 kHz
	MP3(ISO 9660)	96, 112, 128, 256 kbps & variable bit rate fs, 32, 44.1, 48 kHz

Analog Sound Stereo
Dolby Surround compatible downmix from Dolby Digital multi-channel sound
Dolby Pro Logic II
3D sound for virtual 5.1 channel sound on 2 speakers

AUDIO PERFORMANCE

DA Converter	24 bit, 192 kHz	
DVD	fs 96 kHz	4Hz- 44kHz
	fs 48 kHz	4Hz- 22kHz
SVCD	fs 48 kHz	4Hz- 22kHz
	fs 44.1kHz	4Hz- 20kHz
CD/VCD	fs 44.1kHz	4Hz- 20kHz
Signal-Noise (1kHz)		> 95 dB
Dynamic range(1kHz)		> 85 dB
Crosstalk (1kHz)		> 90 dB
Distortion/noise (1kHz)		> 80 dB
MPEG MP3	MPEG Audio L3	

CONNECTIONS

YPbPr Output	Cinch 3x
Video Output	Cinch (yellow)
Audio Output(L+R)	Cinch (white/red)
Digital Output	1 coaxial IEC60958 for CDDA / LPCM IEC61937 for MPEG 1/2, Dolby Digital
6 channel analogue output	
Audio Front L/R	Cinch (white/red)
Audio Rear L/R	Cinch (white/red)
Audio Centre	Cinch (blue)
Audio Subwoofer	Cinch (black)

CABINET

Dimensions (w x h x d)	360 x 37 x 265 mm
Weight	Approximately 2.0 kg

POWER CONSUMPTION

Power Supply Rating	110-240V; 50/60Hz
Power consumption	< 10 W
Power consumption in Standby mode	< 0.8 W

Specifications subject to change without prior notice

01-41 DVP3000K_93_RC2 40 26/09/05, 9:54 AM

Glossary

Analog: Sound that has not been turned into numbers. Analog sound varies, while digital sound has specific numerical values. These jacks send audio through two channels, the left and right.

Aspect ratio: The ratio of vertical and horizontal sizes of a displayed image. The horizontal vs. vertical ratio of conventional TVs. is 4:3, and that of wide-screens is 16:9.

AUDIO OUT Jacks: Jacks on the back of the DVD System that send audio to another system (TV, Stereo, etc.).

Bit Rate: The amount of data used to hold a given length of music; measured in kilobits per seconds, or kbps. Or, the speed at which you record. Generally, the higher the bit rate, or the higher the recording speed, the better the sound quality. However, higher bit rates use more space on a Disc.

Chapter: Sections of a picture or a music piece on a DVD that are smaller than titles. A title is composed of several chapters. Each chapter is assigned a chapter number enabling you to locate the chapter you want.

Component Video Out Jacks: Jacks on the back of the DVD System that send high-quality video to a TV that has Component Video In jacks (R/G/B, Y/Pb/Pr, etc.).

Disc menu: A screen display prepared for allowing selection of images, sounds, subtitles, multi-angles, etc recorded on a DVD.

Digital: Sound that has been converted into numerical values. Digital sound is available when you use the DIGITAL AUDIO OUT COAXIAL or OPTICAL jacks. These jacks send audio through multiple channels, instead of just two channels as analog does.

Dolby Digital: A surround sound system developed by Dolby Laboratories containing up to six channels of digital audio (front left and right, surround left and right, center and subwoofer).

DTS: Digital Theatre Systems. This is a surround sound system, but it is different from Dolby Digital. The formats were developed by different companies.

JPEG: A very common digital still picture format. A still-picture data compression system proposed by the Joint Photographic Expert Group, which features small decrease in image quality in spite of its high compression ratio.

MP3: A file format with a sound data compression system. "MP3" is the abbreviation of Motion Picture Experts Group 1 (or MPEG-1) Audio Layer 3. By using MP3 format. one CD-R or CD-RW can contain about 10 times as much data volume as a regular CD can.

Multichannel: DVD is specified to have each sound track constitute one sound field. Multichannel refers to a structure of sound tracks having three or more channels.

Parental Control: A function of the DVD to limit playback of the disc by the age of the users according to the limitation level in each country. The limitation varies from disc to disc; when it is activated, playback will be prohibited if the software's level is higher than the user-set level.

PCM (Pulse Code Modulation): A system for converting analog sound signal to digital signal for later processing, with no data compression used in conversion.

Playback control (PBC): Refers to the signal recorded on video CDs or SVCDs for controlling reproduction. By using menu screens recorded on a Video CD or SVCD that supports PBC, you can enjoy interactive-type software as well as software having a search function.

Progressive Scan: It displays all the horizontal lines of a picture at one time, as a signal frame. This system can convert the interlaced video from DVD into progressive format for connection to a progressive display. It dramatically increases the vertical resolution.

Region code: A system for allowing discs to be played back only in the region designated beforehand. This unit will only play discs that have compatible region codes. You can find the region code of your unit by looking on the product label. Some discs are compatible with more than one region (or ALL regions).

Surround: A system for creating realistic three-dimensional sound fields full of realism by arranging multiple speakers around the listener.

Title: The longest section of a picture or music feature on DVD, music, etc., in video software, or the entire album in audio software. Each title is assigned a title number enabling you to locate the title you want.

VIDEO OUT jack: Jack on the back of the DVD System that sends video to a TV.

01-41 DVP3000K_93_RC2 41 26/09/05, 9:54 AM